


CL090A-F	CL090AE-F
CL090A-M	CL090AE-M
CL091A-F	CL091AE-F
CL091A-M	CL091AE-M
CL092A-F	CL092AE-F
CL092A-M	CL092AE-M

HS RS-232↔Current Loop Converter Active



**CUSTOMER
SUPPORT
INFORMATION**

Order toll-free in the U.S. 24 hours, 7 A.M. Monday to midnight Friday: **877-877-BBOX**
FREE technical support, 24 hours a day, 7 days a week: Call **724-746-5500** or fax **724-746-0746**
Mail order: **Black Box Corporation**, 1000 Park Drive, Lawrence, PA 15055-1018
Web site: www.blackbox.com • E-mail: info@blackbox.com

**FEDERAL COMMUNICATIONS COMMISSION
AND
CANADIAN DEPARTMENT OF COMMUNICATIONS
RADIO FREQUENCY INTERFERENCE STATEMENTS**

This equipment generates, uses, and can radiate radio frequency energy and if not installed and used properly, that is, in strict accordance with the manufacturer's instructions, may cause interference to radio communication. It has been tested and found to comply with the limits for a Class A computing device in accordance with the specifications in Subpart J of Part 15 of FCC rules, which are designed to provide reasonable protection against such interference when the equipment is operated in a commercial environment. Operation of this equipment in a residential area is likely to cause interference, in which case the user at his own expense will be required to take whatever measures may be necessary to correct the interference.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This digital apparatus does not exceed the Class A limits for radio noise emission from digital apparatus set out in the Radio Interference Regulation of the Canadian Department of Communications.

Le présent appareil numérique n'émet pas de bruits radioélectriques dépassant les limites applicables aux appareils numériques de la classe A prescrites dans le Règlement sur le brouillage radioélectrique publié par le ministère des Communications du Canada.

TRADEMARKS USED IN THIS MANUAL

AT&T is a registered trademark of American Telephone and Telegraph Company.

Any other trademarks mentioned in this manual are acknowledged to be the property of the trademark owners.

**NORMAS OFICIALES MEXICANAS (NOM)
ELECTRICAL SAFETY STATEMENT**

INSTRUCCIONES DE SEGURIDAD

1. Todas las instrucciones de seguridad y operación deberán ser leídas antes de que el aparato eléctrico sea operado.
2. Las instrucciones de seguridad y operación deberán ser guardadas para referencia futura.
3. Todas las advertencias en el aparato eléctrico y en sus instrucciones de operación deben ser respetadas.
4. Todas las instrucciones de operación y uso deben ser seguidas.
5. El aparato eléctrico no deberá ser usado cerca del agua—por ejemplo, cerca de la tina de baño, lavabo, sótano mojado o cerca de una alberca, etc..
6. El aparato eléctrico debe ser usado únicamente con carritos o pedestales que sean recomendados por el fabricante.
7. El aparato eléctrico debe ser montado a la pared o al techo sólo como sea recomendado por el fabricante.
8. Servicio—El usuario no debe intentar dar servicio al equipo eléctrico más allá a lo descrito en las instrucciones de operación. Todo otro servicio deberá ser referido a personal de servicio calificado.
9. El aparato eléctrico debe ser situado de tal manera que su posición no interfiera su uso. La colocación del aparato eléctrico sobre una cama, sofá, alfombra o superficie similar puede bloquea la ventilación, no se debe colocar en libreros o gabinetes que impidan el flujo de aire por los orificios de ventilación.
10. El equipo eléctrico debe ser situado fuera del alcance de fuentes de calor como radiadores, registros de calor, estufas u otros aparatos (incluyendo amplificadores) que producen calor.

11. El aparato eléctrico deberá ser conectado a una fuente de poder sólo del tipo descrito en el instructivo de operación, o como se indique en el aparato.
12. Precaución debe ser tomada de tal manera que la tierra física y la polarización del equipo no sea eliminada.
13. Los cables de la fuente de poder deben ser guiados de tal manera que no sean pisados ni pellizcados por objetos colocados sobre o contra ellos, poniendo particular atención a los contactos y receptáculos donde salen del aparato.
14. El equio eléctrico debe ser limpiado únicamente de acuerdo a las recomendaciones del fabricante.
15. En caso de existir, una antena externa deberá ser localizada lejos de las líneas de energía.
16. El cable de corriente deberá ser desconectado del cuando el equipo no sea usado por un largo periodo de tiempo.
17. Cuidado debe ser tomado de tal manera que objetos líquidos no sean derramados sobre la cubierta u orificios de ventilación.
18. Servicio por personal calificado deberá ser provisto cuando:
 - A: El cable de poder o el contacto ha sido dañado; u
 - B: Objetos han caído o líquido ha sido derramado dentro del aparato; o
 - C: El aparato ha sido expuesto a la lluvia; o
 - D: El aparato parece no operar normalmente o muestra un cambio en su desempeño; o
 - E: El aparato ha sido tirado o su cubierta ha sido dañada.

Contents

1. Specifications.....	5
2. Introduction	6
2.1 Overview.....	6
2.2 Features.....	6
3. Configuration	7
3.1 Setting the DCE/DTE Switch	7
3.2 Setting the Active/Passive Switch	8
4. Installation.....	10
4.1 Twisted-Pair Wiring.....	10
4.1.1 Twisted-Pair Connection Using Terminal Blocks	10
4.1.2 Twisted-Pair Connection Using Modular Jacks	15
4.2 Completing the Installation.....	16
Appendix A. RS-232C Pin Connections.....	17
Appendix B. Block Diagram.....	18

1. Specifications

Data Rates	Up to 115.2 Kbps
Connectors	<p><i>RS-232 side</i>—CL090A-F, CL091A-F, CL092A-F, CL090AE-F, CL091AE-F, CL092AE-F: DB25 female; CL090A-M, CL091A-M, CL092A-M, CL090AE-M, CL091AE-M, CL092AE-M: DB25 male</p> <p><i>Current-Loop side</i>—CL090A-F, CL090A-M, CL090AE-F, CL090AE-M: Terminal block with strain relief; CL091A-F, CL091A-M, CL091AE-F, CL091AE-M: RJ-11; CL092A-F, CL092A-M, CL092AE-F, CL092AE-M: RJ-45</p>
Operation	Transmitter is always active; receiver can be configured as active or passive with a switch
Transmission Line	19- to 26-AWG twisted pair
Range	4 miles (6.4 km) on 24-AWG twisted pair
Interfaces	Asynchronous, EIA RS-232, CCITT V.24 full duplex, 20-mA current loop
Indicators	TD, RD, PWR
Isolation	1500V RMS via opto-isolators
Operating Temperature	32° to 140°F (0° to 60°C)
Humidity	0 to 95%, noncondensing
Altitude	Up to 15,000 feet (4570 m)
Power	9 VDC at 500 mA; 110 VAC/60 Hz or 220 VAC/50 Hz
Size	2.7"H x 0.7"W x 2.1"D (6.9 x 1.8 x 5.3 cm)
Weight	1.5 oz. (42.5 g)

2. Introduction

2.1 Overview

The HS RS-232↔Current Loop Converter Active lets an asynchronous RS-232 device communicate with a passive 20-mA current-loop device. Equipped with an external power supply, the Converter supports data rates up to 115.2 Kbps. The HS RS-232↔Current Loop Converter Active transmitter is active and must be connected to a passive receiver, and the HS RS-232↔Current Loop Converter Active receiver can accommodate either a passive or active transmitter.

Operating at full duplex, the HS RS-232↔Current Loop Converter Active supports communication distances up to 4 miles (6.4 km) over two unconditioned 24-AWG twisted pairs. To guard against data loss due to ground loops, the Converter is equipped with 1500V RMS optical isolators on the line side.

The HS RS-232↔Current Loop Converter Active connects directly to the RS-232 interface using a male or female DB25 connector. An external DCE/ DTE switch eliminates the need for a crossover cable on the RS-232 interface.

2.2 Features


- Full-duplex, asynchronous transmission over 4 wires.
- Data rates up to 115.2 Kbps.
- Optically isolated.
- Twisted-pair connection via terminal blocks, RJ-11, or RJ-45 jacks.
- External DCE/DTE switch.
- Receiver operates actively or passively; transmitter is active only.
- LEDs monitor transmit data, receive data, and power.
- DB25 male or female connectors on RS-232 side.
- Range to 4 miles (6.4 km) on 24-AWG twisted pair.

3. Configuration

The HS RS-232↔Current Loop Converter Active is easy to use. The only configuration necessary for operation is the proper setting of two switches: the external DCE/DTE switch and the internal active/passive switch.

3.1 Setting the DCE/DTE Switch


The figure below shows the location of the DCE/DTE switch on the PC board, as well as the location of the terminal block.



HS RS-232↔CURRENT LOOP CONVERTER ACTIVE

For your convenience, the Converter has an externally accessible DCE/DTE switch (see the diagram below). If the RS-232 device connected to the Converter is a modem or multiplexor (or is wired like DCE), set the switch to “DTE.” The setting causes the Converter to behave like Data Terminal Equipment, transmitting data on RS-232 pin 2 and receiving data on pin 3.

If the RS-232 device connected to the Converter is a PC, terminal, or host computer (or is wired like DTE), set the switch to “DCE.” This setting causes the Converter to behave like Data Communications Equipment, transmitting data on RS-232 pin 3 and receiving data on pin 2. Remember, the switch setting is always from the point of view of the HS RS-232↔ Current Loop Converter Active, not the connected equipment.




3.2 Setting the Active/Passive Switch

The active/passive switch is used to control the mode of the receiver; it has no control over the transmitter since the transmitter is fixed in the active mode.

To configure your HS RS-232↔Current Loop Converter Active receiver, you first need to determine whether your device will be active or passive. If you are going to use the HS RS-232↔Current Loop Converter Active receiver to provide current for the loop, set the switch to the “active” position. If the HS RS-232↔Current Loop Converter Active is to be used in an active loop, set the HS RS-232↔Current Loop Converter Active receiver’s active/passive switch to passive.

CAUTION

Never connect two active devices together. Your configuration must be "active to passive" or "passive to active."




4. Installation

The HS RS-232↔Current Loop Converter Active is simple to install. After configuring the DCE/DTE and active/passive switches, connect the two twisted pairs using one of three methods: terminal blocks with strain relief, RJ-11 jack, or RJ-45 jack. The method you use will depend on the specific model you have. (See **Chapter 1** if you aren't sure which method you should use.)

4.1 Twisted-Pair Wiring



Only one HS RS-232↔Current Loop Converter Active is needed for each RS-232 to 20-mA current-loop circuit. The HS RS-232↔Current Loop Converter Active is connected to the current-loop device using two twisted pairs. The pairs must be “dry” (unconditioned) metallic wire, 19 to 26 AWG. Best distance is achieved with smaller gauges (that is, thicker wires). When you have completed wiring for your data circuit, the pin connections should be as shown below:



4.1.1 TWISTED-PAIR CONNECTION USING TERMINAL BLOCKS


The terminal block/strain-relief version of the HS RS-232↔Current Loop Converter Active (CL090A-F, CL090A-M, CL090AE-F, CL090AE-M) allows you to hook up the line-side interface using bare wires. The following instructions will tell you how to open the case, connect the bare wires, and fasten the strain-relief collar in place.

1. Open the unit by gently inserting a screwdriver between the DB25 connector and the lip of the plastic case (see the diagram below). You don't have to worry about breaking the plastic, but be careful not to bend the D-sub connector.




Once the unit has been opened, you will be able to see the terminal blocks located at the rear of the PC board.

2. Strip the outer insulation from the twisted pairs about one inch from the end.



3. Strip back the insulation on each of the two twisted-pair wires about one quarter of an inch.




4. Connect *one pair of wires* in the telephone cable to XMT (Transmit) on the terminal block, being careful to observe the polarity. (The wire connected to XMT+ must be connected at the other end of the telephone line to RCV+ in the other unit. The wire connected to XMT- must be connected at the other end of the telephone line to RCV- in the other unit.)


5. Connect *the other pair of wires* in the telephone cable to RCV (Receive), again being careful to observe the polarity. (The wire connected to RCV+ must be connected at the other end of the telephone line to XMT+ in the other unit. The wire connected to RCV- must be connected at the other end of the telephone line to XMT- in the other unit.)

6. If there is a shield around the telephone cable, it may be connected to “G” on the terminal block. To avoid ground loops, we recommend connecting the shield at the computer end only. *A ground wire is not necessary for proper operation of these units.*


7. When you finish connecting the wires to the terminal block, the assembly should resemble the diagram below.




8. Place the two halves of the strain-relief assembly on either side of the telephone wire and press together very lightly. Slide the assembly so that it is about two inches (5.1 cm) from the terminal posts and press together firmly. If your cable diameter is too small or too large for our strain relief, contact your supplier for technical support.



9. Insert the strain-relief assembly with the wire going through it into the slot in the bottom half of the converter case and set it into the recess in the case. If the telephone wire does not fit, contact your supplier for technical support.



10. Bend the top half of the case as necessary to place it over the strain-relief assembly. Do not snap the case together yet.



11. Insert one captive screw through a saddle washer, then insert the captive screw with the washer on it through the hole in the DB25 end of the case. Snap that side of the case closed. Repeat the process for the other side. Cable installation is complete.


4.1.2 TWISTED-PAIR CONNECTION USING MODULAR JACKS

The modular versions of the HS RS-232↔Current Loop Converter Active have an RJ-11 (CL091A-F, CL091A-M, CL091AE-F, CL091AE-M) or RJ-45 (CL092A-F, CL092A-M, CL092AE-F, CL092AE-M) jack mounted in the case. These jacks are prewired for a standard telco wiring environment. To be sure you have the right wiring, use the table below as a guide.


<u>RJ-11</u>	<u>Signal</u>
1.....	GND†
2.....	RCV-
3.....	XMT+
4.....	XMT-
5.....	RCV+
6.....	GND

<u>RJ-45</u>	<u>Signal</u>
1.....	N/C
2.....	GND
3.....	RCV-
4.....	XMT+
5.....	XMT-
6.....	RCV+
7.....	GND
8.....	N/C

†Connection to ground is optional



- 1 - Blue
- 2 - Yellow
- 3 - Green
- 4 - Red
- 5 - Black
- 6 - White



- 1 - Blue
- 2 - Orange
- 3 - Black
- 4 - Red
- 5 - Green
- 6 - Yellow
- 7 - Brown
- 8 - Slate

Figure 1. AT&T® standard color codes.


4.2 Completing the Installation

Once you have configured the Converter for DCE or DTE and connected the twisted-pair wires correctly, simply plug the Converter into the RS-232 data port. Remember to insert and tighten the two captive connector screwlocks.


The PWR light remains on as long as the power supply is connected and supplying power. When the data is transmitted or received, the TD and RD lights will flicker or appear to remain on (depending on the baud rate).

The HS RS-232↔Current Loop Converter Active requires 9 volts of DC power. A 110- (for the “A” models) or 220-volt (for the “AE” models) power supply is included with your Converter.

Appendix A. RS-232C Pin Connections

Pin	Signal
1	FG
2	TD
3	RD
4	
5	
6	
8	
20	
7	GND
9	+V

Appendix B. Block Diagram





© Copyright 1996. Black Box Corporation. All rights reserved.

1000 Park Drive • Lawrence, PA 15055-1018 • 724-746-5500 • Fax 724-746-0746