




Modular Current Loop Adapter



**CUSTOMER
SUPPORT
INFORMATION**

Order toll-free in the U.S.: Call **877-877-BBOX** (outside U.S. call **724-746-5500**)
FREE technical support 24 hours a day, 7 days a week: Call **724-746-5500** or fax **724-746-0746**
Mailing address: **Black Box Corporation**, 1000 Park Drive, Lawrence, PA 15055-1018
Web site: www.blackbox.com • E-mail: info@blackbox.com

MODULAR CURRENT LOOP ADAPTER

TRADEMARKS USED IN THIS MANUAL

Any trademarks mentioned in this manual are acknowledged to be the property of the trademark owners.

Contents

Chapter	Page
1. Specifications	4
2. Description	5
3. Configuration and Installation	6
3.1 RS-232 Interface.....	6
3.1.1 DCE or DTE Configuration	6
3.1.2 Connecting the RS-232 Device	6
3.2 Current-Loop Interface.....	7
3.2.1 Full-Duplex Operation	8
3.2.2 Half-Duplex Operation	10
3.2.3 Connecting the Current-Loop Device	11

1. Specifications

Speed —	Up to 19.2 Kbps
Maximum Distance —	1000 ft. (304.8 m)
Operation —	Passive, 20-mA current loop, unipolar, mark=current, space=no current
Interface —	RS-232/V.24, DCE or DTE (switch-selectable), 20-mA current loop
Connectors —	RS-232: (1) DB25 male for CL512A-M, (1) DB25 female for CL512A-F; Current Loop: (1) four-position screw terminal strip and (1) RJ-11 (4-wire)
Enclosure —	Metal
Power —	+12 volts must be provided by EIA Interface (Pin 6 when unit is configured as a DTE, Pin 20 when configured as a DCE); current provided by external “active” device (20 mA, 24 VDC max.), optically isolated for RS-232 signal protection
Size —	0.9" H x 2.1" W x 3" D (2.3 x 5.3 x 7.6 cm)
Weight —	2.1 oz. (59.5 g)

2. Description

The Modular Current Loop Adapter connects current-loop equipment such as industrial controllers and Data General computers to RS-232 equipment such as modems, multiplexors, computers and terminals. The unit is a “passive” device: this means it does not provide current for the current loop. The “passive” adapter must connect to an “active” current-loop device. The “active” device provides the 20-mA current for the loop. (There can be only one active device in the current loop.) The RS-232 interface of the attached equipment must provide a +12 voltage on either pin 6 or pin 20 to power the adapter.

3. Configuration and Installation

3.1 RS-232 Interface

3.1.1 DCE OR DTE CONFIGURATION

The adapter connects easily to an RS-232 device such as a DTE (terminal, computer) or DCE (modem, line driver, multiplexor).

The attached RS-232 device supplies power to the adapter via a positive (+12) voltage on the adapter's pin 20 (if the unit is configured as DCE) or pin 6 (if the unit is configured as DTE). Pinnings for both configurations are shown below.

DTE	DCE
Pin 2 = TD (output)	Pin 2 = TD (input)
Pin 3 = RD (input)	Pin 3 = RD (output)
Pin 6 = DSR (input)	Pin 20 = DTR (input)
Pin 7 = Signal Ground	Pin 7 = Signal Ground

To configure the adapter, simply move the external switch to the DTE or DCE position. If you are going to plug the adapter into a DTE, move the adapter switch to the DCE position. If you are going to plug the adapter into a DCE, move the adapter switch to the DTE position.

3.1.2 CONNECTING THE RS-232 DEVICE

To connect the adapter to the RS-232 device, simply plug the unit's DB25 connector into your RS-232 equipment's DB25 connector. (The unit is available in both male and female versions to accommodate your equipment.)

3.2 Current-Loop Interface

Review the following pinning guidelines before you connect the twisted-pair cable from your current-loop device to the adapter's RJ-11 port or four-position screw terminal. Figure 3-1 shows the pin positions for both connectors.




Figure 3-1. Pin Positions for RJ-11 and Terminal Screw Block.

Connections on the current-loop side of the adapter may be full- or half-duplex. In full-duplex transmission, both the adapter and the current-loop device may send and receive data simultaneously. In half-duplex transmission, only one device at a time may send or receive data. **Section 3.2.1** describes full-duplex connections and **Section 3.2.2** discusses half-duplex connections.

3.2.1 FULL-DUPLEX OPERATION

Table 3-1. Pinouts for Full-Duplex Current-Loop Connections

<p>RJ-11 Modular Pinnings:</p> <p>1 = RX+, connect to the TX+ of your device. 2 = TX-, connect to the RX- of your device. 3 = TX+, connect to the RX+ of your device. 4 = RX-, connect to the TX- of your device.</p>
<p>Terminal Block Pinnings:</p> <p>1 = TX+, connect to the RX+ of your device. 2 = TX-, connect to the RX- of your device. 3 = RX+, connect to the TX+ of your device. 4 = RX-, connect to the TX- of your device.</p>

Typical full-duplex applications for the adapter are shown in Figures 3-2 and 3-3. In Figure 3-2, the unit is connected to a DTE device. In Figure 3-3, the unit is connected to a DCE device.

NOTE

When connected to a DTE device, the adapter does not output pins 5 (CTS), 6 (DSR), or 8 (CD). If your computer (DTE) needs these pins before it can send data, you must use a short cable with the proper pin configuration between the computer and the unit. This entails looping pin 4 (RTS) or any other signal at 12 volts to pins 5, 6, and 8 on the side connected to the computer.

When connected to a DCE device, the adapter does not output pins 4 (RTS) or 20 (DTR), which your modem may need before it can send data. If your modem needs these pins, you must use a short cable with the proper pin configuration between the modem and the unit. This involves looping pin 8 (CD) or any other signal on the interface that is at +12 V to pins 4 and 20 on the side connected to the modem.




Figure 3-2. Full-Duplex DTE Operation.




Figure 3-3. Full-Duplex DCE Operation.

3.2.2 HALF-DUPLEX OPERATION

Table 3-2. Pinouts for Half-Duplex Current-Loop Connections

RJ-11 Modular Pinnings* 3 = + Loop Jumper 1 to 2 4 = - Loop
Terminal Block Pinnings 1 = + Loop Jumper 2 to 3 4 = - Loop

*Half-duplex operation is not recommended for RJ-11 connections due to the difficulty involved in crossing Jumpers 2 and 3.

Typical half-duplex applications for the adapter are shown in Figures 3-4 and 3-5. In Figure 3-4, the unit is connected to a DTE device. In Figure 3-5, the unit is connected to a DCE device.

NOTE

When connected to a DTE device, the adapter does not output pins 5 (CTS), 6 (DSR), or 8 (CD). If your computer needs these pins before it can send data, you must use a short cable with the proper pin configuration between the computer and the unit. This entails looping pin 4 (RTS) or any other signal at +12 volts to pins 5, 6, and 8 on the side connected to the computer.

When connected to a DCE device, the adapter does not output pins 4 (RTS) or 20 (DTR). If your modem needs these pins before it can send data, you must use a short cable with the proper pin configuration between the modem and the unit. This involves looping pin 8 (CD) or any other signal on the interface that is at +12V to pins 4 and 20 on the side connected to the modem.

HALF-DUPLEX (2-WIRE)




Figure 3-4. Half-Duplex DTE Operation.

HALF-DUPLEX (2-WIRE)




Figure 3-5. Half-Duplex DCE Operation.

3.2.3 CONNECTING THE CURRENT-LOOP DEVICE

If you're using the RJ-11 port on the adapter, simply plug the cable from the current-loop device into the RJ-11 port.

If you're using the screw terminal, wrap one of the 2- or 4-wire twisted pairs from the current-loop device around each of the screw terminals.



© Copyright 1998. Black Box Corporation. All rights reserved.

1000 Park Drive • Lawrence, PA 15055-1018 • 724-746-5500 • Fax 724-746-0746