




BLACK BOX[®]
NETWORK SERVICES



MARCH 2000
IC602C
IC186C

Single Channel Parallel/Serial I/O Interface



**CUSTOMER
SUPPORT
INFORMATION**

Order **toll-free** in the U.S. 24 hours, 7 A.M. Monday to midnight Friday: **877-877-BBOX**
FREE technical support, 24 hours a day, 7 days a week: Call **724-746-5500** or fax **724-746-0746**
Mail order: **Black Box Corporation**, 1000 Park Drive, Lawrence, PA 15055-1018
Web site: www.blackbox.com • E-mail: info@blackbox.com

SINGLE CHANNEL PARALLEL/SERIAL I/O INTERFACE

TRADEMARKS USED IN THIS MANUAL

All applied-for and registered trademarks are the property of their respective owners.

**FEDERAL COMMUNICATIONS COMMISSION
AND
CANADIAN DEPARTMENT OF COMMUNICATIONS
RADIO FREQUENCY INTERFERENCE STATEMENTS**

This equipment generates, uses, and can radiate radio frequency energy and if not installed and used properly, that is, in strict accordance with the manufacturer's instructions, may cause interference to radio communication. It has been tested and found to comply with the limits for a Class A computing device in accordance with the specifications in Subpart J of Part 15 of FCC rules, which are designed to provide reasonable protection against such interference when the equipment is operated in a commercial environment. Operation of this equipment in a residential area is likely to cause interference, in which case the user at his own expense will be required to take whatever measures may be necessary to correct the interference.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This digital apparatus does not exceed the Class A limits for radio noise emission from digital apparatus set out in the Radio Interference Regulation of the Canadian Department of Communications.

Le présent appareil numérique n'émet pas de bruits radioélectriques dépassant les limites applicables aux appareils numériques de classe A prescrites dans le Règlement sur le brouillage radioélectrique publié par le ministère des Communications du Canada.

NORMAS OFICIALES MEXICANAS (NOM) ELECTRICAL SAFETY STATEMENT

INSTRUCCIONES DE SEGURIDAD

1. Todas las instrucciones de seguridad y operación deberán ser leídas antes de que el aparato eléctrico sea operado.
2. Las instrucciones de seguridad y operación deberán ser guardadas para referencia futura.
3. Todas las advertencias en el aparato eléctrico y en sus instrucciones de operación deben ser respetadas.
4. Todas las instrucciones de operación y uso deben ser seguidas.
5. El aparato eléctrico no deberá ser usado cerca del agua—por ejemplo, cerca de la tina de baño, lavabo, sótano mojado o cerca de una alberca, etc..
6. El aparato eléctrico debe ser usado únicamente con carritos o pedestales que sean recomendados por el fabricante.
7. El aparato eléctrico debe ser montado a la pared o al techo sólo como sea recomendado por el fabricante.
8. Servicio—El usuario no debe intentar dar servicio al equipo eléctrico más allá a lo descrito en las instrucciones de operación. Todo otro servicio deberá ser referido a personal de servicio calificado.
9. El aparato eléctrico debe ser situado de tal manera que su posición no interfiera su uso. La colocación del aparato eléctrico sobre una cama, sofá, alfombra o superficie similar puede bloquea la ventilación, no se debe colocar en libreros o gabinetes que impidan el flujo de aire por los orificios de ventilación.
10. El equipo eléctrico deber ser situado fuera del alcance de fuentes de calor como radiadores, registros de calor, estufas u otros aparatos (incluyendo amplificadores) que producen calor.

11. El aparato eléctrico deberá ser conectado a una fuente de poder sólo del tipo descrito en el instructivo de operación, o como se indique en el aparato.
12. Precaución debe ser tomada de tal manera que la tierra física y la polarización del equipo no sea eliminada.
13. Los cables de la fuente de poder deben ser guiados de tal manera que no sean pisados ni pellizcados por objetos colocados sobre o contra ellos, poniendo particular atención a los contactos y receptáculos donde salen del aparato.
14. El equipo eléctrico debe ser limpiado únicamente de acuerdo a las recomendaciones del fabricante.
15. En caso de existir, una antena externa deberá ser localizada lejos de las líneas de energía.
16. El cable de corriente deberá ser desconectado del cuando el equipo no sea usado por un largo periodo de tiempo.
17. Cuidado debe ser tomado de tal manera que objetos líquidos no sean derramados sobre la cubierta u orificios de ventilación.
18. Servicio por personal calificado deberá ser provisto cuando:
 - A: El cable de poder o el contacto ha sido dañado; u
 - B: Objetos han caído o líquido ha sido derramado dentro del aparato; o
 - C: El aparato ha sido expuesto a la lluvia; o
 - D: El aparato parece no operar normalmente o muestra un cambio en su desempeño; o
 - E: El aparato ha sido tirado o su cubierta ha sido dañada.

Table of Contents

Chapter	Page
1. Specifications.....	7
2. Introduction	8
3. Serial Port Address/Option Selection	11
3.1 Address Selection.....	11
3.2 Option Selection.....	12
3.2.1 Port Enable/Disable.....	12
3.2.2 Interface Selection	12
3.2.3 E1 Jumper for RS-232 Interface Option	13
3.2.4 RS-422 Interface Options.....	13
3.2.5 RS-485 Interface Options.....	14
4. Parallel Port Address/Option Selection	16
4.1 Address Selection.....	16
4.2 Option Selection.....	16
4.2.1 E4.....	16
4.2.2 E3.....	17
5. Installation	18
Appendix. Block Diagram.....	20

1. Specifications

Speed	IC602C: Up to 115.2 Kbps; IC186C: 460.8 kbps and higher; Maximum data rate is dependent on software, CPU, and cable length
Protocol	Asynchronous only
Connectors	(1) DB9 male [serial], (1) DB25 female [parallel]
Communications Chip	IC602C: 16550 UART; IC186C: 16950 UART
System Requirements	ISA Bus
Diagnostics	(Included) utility software
Operating Temperature	32 to 122°F (0 to 50°C)
Storage Temperature	-4 to 158°F (-20 to 70°C)
Relative Humidity	90%, noncondensing
MTBF	> 150,000 hours
Power	From PC bus
Board Size	¾-size card
Shipping Weight	2 lb. (0.9 kg)

2. Introduction

The Single Channel Parallel/Serial I/O Interface provides two functions: A Centronics parallel port (DB25 female connector) and a serial port (DB9 male connector) that supports both RS-232 and RS-422/485.

Serial port features include:

- DB9 male connector mounted above the DB25 female printer connector on board bracket.
- Port can be addressed as COM1: (3F8 Hex), COM2: (2F8 Hex), COM3: (3E8 Hex), or COM4: (2E8 Hex), or any other I/O address from 0 to 3FF Hex.
- IRQs 3, 4, 5, 9, 10, 11, 12, and 15.
- Interrupts can be shared with other sharable interrupts.
- RS-232C interface with all standard PC signals (TD, RD, RTS, CTS, DSR, DCD, DTR, RI), or RS-422 interface with the TD, RD, RTS, CTS signals.
- Serial port interface is determined by jumper selection.

Parallel port features include:

- IBM and Centronics compatible parallel-printer port.
- User-selectable (via DIP switch) addresses of LPT1 through 3; any other I/O addresses are from 200 to 3FF Hex.
- IRQs 3, 4, 5, 7, 10, 11, 12, and 15.
- Interrupts can be shared with other sharable interrupts.
- Provides a DB25 female connector with the Centronics parallel-printer pinout standard in the PC industry.
- Jumper E (position B) is provided to allow the port to operate bi-directionally, as some PS/2 models do.

The Single Channel Parallel/Serial I/O Interface board (IC602C) uses the same 16550 UART chip found in the IBM asynchronous adapter. This chip features programmable baud rate, data format, and interrupt control. Refer to the *IBM Technical Reference* for details on programming the chip. The serial port can be set as COM1: through COM4:, providing total compatibility with most communications software and languages. The IC186C uses the 16950 UART chip for even better performance.

RS-232 or RS-422/485 drivers and receivers are on the serial port. RS-422 allows very-long-distance (5000 feet or 1524 m at 9600 baud) communications with virtually error-free differential-drive characteristics. RS-485 is backwardly compatible with RS-422, but is mainly used for partyline or multi-drop applications.

The output of the RS-422/485 driver is capable of being active (ON) or tri-state (OFF). This allows multiple PCs (or other RS-422/485 devices) to be connected in a multi-drop bus and selectively polled. Half-duplex two-wire operation is also possible by connecting TX+ to RX+ and TX- to RX- (in the connector hood). The driver can be enabled by the UART Request To Send (RTS) line or optionally tied high (permanently enabled) for four-wire operation only. To permanently enable the driver, move jumper position “E” on E1 to position “A.”

Table 2-1. DB9 Connector Pinout, RS-232 Interface

Signal Name		Pin #	Mode
TD	Transmit Data	3	Output RS-232
RTS	Request to Send	7	Output RS-232
RD	Receive Data	2	Input RS-232
CTS	Clear to Send	8	Input RS-232
GND	Ground	5	
DCD	Data Carrier Detect	1	Input RS-232
DSR	Data Set Ready	6	Input RS-232
DTR	Data Terminal Ready	4	Output RS-232
RI	Ring Indicator	9	Input RS-232

SINGLE CHANNEL PARALLEL/SERIAL I/O INTERFACE

Table 2-2. DB9 Connector Pinout, RS-422/485 Interface

Signal Name			Pin #	Mode
GND	Ground		5	
RDB	RX+	Receive Positive	1	Input RS-422
RDA	RX-	Receive Negative	2	Input RS-422
CTSB	CTS+	Clear to Send Positive	9	Input RS-422
CTSA	CTS-	Clear to Send Negative	8	Input RS-422
TDB	TX+	Transmit Positive	4	Output RS-422
TDA	TX-	Transmit Negative	3	Output RS-422
RTSB	RTS+	Request To Send Positive	6	Output RS-422
RTSA	RTS-	Request To Send Negative	7	Output RS-422

Line Termination

Typically, each end of the RS-422/485 bus must have line-terminating resistors. A 100-ohm resistor is across each RS-422/485 input and a 1-Kohm pull-up/pull-down combination bias the receiver inputs. If multiple (more than two) RS-485 nodes are configured in a multi-drop network, only the nodes at each end of the bus should have the 100-ohm resistors installed.

If non-standard baud rates are required, such as 31.25 or 76.8 Kbps, location Y1 allows a different oscillator to be installed. Contact your supplier for more information.

3. Serial Port Address/Option Selection

3.1 Address Selection

The Serial Port on the Single Channel Parallel/Serial I/O Interface occupies 8 consecutive I/O locations. A DIP switch (SW2) is used to set the base address for these locations. Be careful when selecting the base address, since some selections conflict with existing PC ports. The following table shows several examples that usually do not cause a conflict.

Address		Binary		SW2 Switch Position Setting							
		A9	A0	1	2	3	4	5	6	7	
280-287		10	1000	0XXX	OFF	ON	OFF	ON	ON	ON	ON
2A0-2A7		10	1010	0XXX	OFF	ON	OFF	ON	OFF	ON	ON
1A0-1A7		01	1010	0XXX	ON	OFF	OFF	ON	OFF	ON	ON
2F8-2FF	COM2:	10	1111	1XXX	OFF	ON	OFF	OFF	OFF	OFF	OFF
3F8-3FF	COM1:	11	1111	1XXX	OFF	OFF	OFF	OFF	OFF	OFF	OFF
2E8-2EF	COM4:	10	1110	1XXX	OFF	ON	OFF	OFF	OFF	ON	OFF
3E8-3EF	COM3:	11	1110	1XXX	OFF	OFF	OFF	OFF	OFF	ON	OFF
320-327		11	0010	0XXX	OFF	OFF	ON	ON	OFF	ON	ON
328-32F		11	0010	1XXX	OFF	OFF	ON	ON	OFF	ON	OFF

If you don't see an address in the table that's compatible with your software, you can determine the switch setting for a particular address by using the table on the next page. This table shows the correlation between the DIP-switch setting and the address bits used to determine the base address. In this example, the address 300 Hex through 307 Hex is selected. 300 Hex equals 11 0000 0XXX in binary representation.

SINGLE CHANNEL PARALLEL/SERIAL I/O INTERFACE

Address	Binary	SW2 Switch Position						
		1	2	3	4	5	6	7
300	A9-----A0 11 0000 0XXX	OFF	OFF	ON	ON	ON	ON	ON

NOTE

Setting the switch ON (or closed) corresponds to a “0” in the address, while leaving it OFF (or open) corresponds to a “1.”

3.2 Option Selection

The board contains several jumper straps for each port which must be set for proper operation. For proper jumper location, refer to the block diagram in the Appendix.

3.2.1 PORT ENABLE/DISABLE

The serial port on the Single Channel Parallel/Serial I/O Interface can be enabled or disabled with switch-position 8 on the DIP switch SW2. The port is enabled with the switch “ON” and disabled when “OFF” or “OPEN.”

3.2.2 INTERFACE SELECTION

E2 connects the DB9 connector to either RS-232 interface circuits, or to the RS-422/485 interface circuits. The table below shows the settings.

Interface	Jumper Position
RS-232	E2 “RS-232”
RS-422/485	E2 “RS-422”

Note that on E2 you must move all eight push-on jumpers. This will completely isolate RS-232 circuits from RS-422/485 circuits and vice versa. On E1, however, there are several jumper options.

3.2.3 E1 JUMPER SETTING FOR RS-232 INTERFACE OPTION

The “A” position is the normal (RS-232) position for all eight jumpers, assuming that the interface requires or uses, all of the modem control signals.

Table 3-1. Jumper E1 (Set for RS-232)

GND	o[00]	Ground	“A” selects normal ground for RS-232.
E	o[00]	Enable	“A” (not applicable to RS-232).
CTS	o[00]		“A” selects RS-232 receive data.
RI	o[00]	Ring Indicator	“A” enables RI; “B” sets it true.
CD	o[00]	Carrier Detect	“A” selects RS-232.
DSR	o[00]	Data Set Ready	“A” selects RS-232.
CTS	o[00]	Clear To Send	“A” selects RS-232.
RD	o[00]	Receive Data	“A” selects RS-232.

B A

3.2.4 RS-422 INTERFACE OPTIONS

E1 provides jumper options for RS-422. The normal position is “B” for all eight jumpers with the following exceptions:

Table 3-2. Jumper E1 (Set for RS-422)

GND	[00]o	Ground	“B” selects 100-ohm ground for RS-422.
E	o[00]	Enable	“A” for RS-422.
CTS	o[00]		“A” selects RS-422 CTS signal (“B” to set true).
RI	[00]o	Ring Indicator	(not used on RS-422); “B” sets it true.
CD	[00]o	Carrier Detect	“B” sets it true.
DSR	[00]o	Data Set Ready	“B” sets it true.
CTS	[00]o	Clear To Send	“B” RS-422; remove if CTS set true.
RD	[00]o	Receive Data	“B” selects RS-422.

B A

SINGLE CHANNEL PARALLEL/SERIAL I/O INTERFACE

3.2.5 RS-485 INTERFACE OPTIONS

E1 also provides jumper options for RS-485. The normal position is “B” for all eight jumpers with the following exceptions:

Table 3-3. Jumper E1 (Set for RS-485)

GND	[00]0	Ground	“B” selects 100-ohm ground for RS-485.
E	[00]0	RTS enable	“B” for RS-485.
CTS	0[00]		“A” selects RS-485 CTS signal (“B” to set true).
RI	[00]0	Ring Indicator	(not used on RS-485); “B” sets it true.
CD	[00]0	Carrier Detect	“B” sets it true.
DSR	[00]0	Data Set Ready	“B” sets it true.
CTS	[00]0	Clear To Send	“B” RS-485; remove if CTS set true.
RD	[00]0	Receive Data	“B” selects RS-485.

B A

E1

Position “E” determines whether the RS-485 driver is enabled by the UART signal Request To Send (RTS) or always enabled. With the jumper installed in position “B,” RTS enables the driver. Moving the jumper to position “A” enables the driver regardless of RTS. This jumper should only be set to “B” if you are running the board in a multi-drop polled environment such as RS-485, and you have software that knows how to “talk” on the RS-485 bus. For normal point-to-point RS-422 (such as terminal emulation), select jumper position “A.”


Position “GND” determines whether the board provides a direct ground connection (as in RS-232 and most RS-422), or a 100-ohm high-impedance ground normally used in RS-485 (and some RS-422) to avoid ground-loop currents with long cables.

E5

E5 selects the interrupt request for the serial port. If COM1: is selected, this jumper must be on the IRQ4 setting. If COM2: is selected, this jumper must be on IRQ3. Consult your particular software for IRQ selection. If no interrupt is desired, remove the jumper. IRQ 2/9 selects IRQ2 on XT

4.2.2 E3

“M” and “N”—placing the jumper on “N” selects the normal (“N”) single interrupt per board mode. Placing the jumper on “M” selects the multi-interrupt (“M”) mode. The multi-interrupt mode allows you to share the IRQ signal(s) with other cards that support multiple interrupts. The “M” and “N” selections for the parallel port are under “PP.”



“B” and “N”—placing the jumper in the “N” normal setting configures the parallel port as an output-only normal PC printer port. Position “B” (for bidirectional) allows the port to be run bidirectionally with software control of the port’s input/output mode. With the “B” position selected, the following assembly-language software will toggle the input/output mode. A base address of 378 is assumed.

To set input mode:

```

MOV DX, 37AH      ;Set DX to Point to Control Register
IN AL, DX        ;Get Old Port Data
OR AL,20H        ;Or in Bit D5 to Turn Output Port Off
OUT DX, AL       ;Output New Value
    
```

To set output mode:

```

MOV DX, 37AH      ;Set DX to Point to Control Register
IN AL, DX        ;Get Old Port Data
AND AL,DFH       ;And in Bit D5 to Turn Output Port On
OUT DX, AL       ;Output New Value
    
```

NOTE

The port powers up Reset as a normal output printer port, even if jumper selection “B” is selected.

5. Installation

IMPORTANT

You **MUST** set up the operating system **BEFORE** you physically install the Card.

5.1 Software Installation

If you are installing an ISA adapter in DOS, OS/2®, or QNX, please refer to the appropriate directory on one of the Serial Utilities Disks for instructions.

5.1.1 WINDOWS 3.1X

Please refer to the /WINDOWS sub-directory on the Serial Utilities Diskette for help files and current information on the installation of the Card in this operating environment.

5.1.2 WINDOWS 95/98 USERS

For the ISA card, run setup on disk two of the Serial Utilities Diskettes before installing the card. Make note of the resources that Windows assigns the adapter, and set the adapter to match those resources. Power down the computer and install the adapter as described in **Section 5.2**. If you wish to change any resources assigned to the adapter, refer to the help file installed in the Black Box folder in the **Start, Programs** menu.

5.1.3 WINDOWS NT

For the ISA card, run setup on disk two of the Serial Utilities Diskettes before installing the card. After installing the software, refer to the help file that automatically comes up for installation instructions.

5.2 Hardware Installation

The Single Channel Parallel/Serial I/O Interface can be installed in any of the PC expansion slots except J8 on the original IBM XT and portable.


To install the card:

- Remove the PC case.
- Remove the screw holding the blank metal slot cover.
- Remove the blank metal slot cover.
- Gently insert the board.
- Replace the blank metal slot cover.
- Replace the screw.
- Replace the PC case.

Installation is complete.

SINGLE CHANNEL PARALLEL/SERIAL I/O INTERFACE

Appendix. Block Diagram



For in-depth schematic detail, call for technical support.



© Copyright 2000. Black Box Corporation. All rights reserved.

1000 Park Drive • Lawrence, PA 15055-1018 • 724-746-5500 • Fax 724-746-0746