

## **Ericsson 700 Cellular Phone Clip**

### **Operating Instructions**

Remove the rubber bung covering the screw hole in the back of the phone. Attach the button to the rectangular pad and screw the assembly to the rear of the phone using the screw supplied.

Use the belt clip with the button for safety and comfort in transportation. To attach the phone and phone clip to the belt clip, slide the phone clip's button into the groove in the belt clip. Slide it down until you hear it click into place. To remove the phone and phone clip from the belt clip, press the button on the bottom of the belt clip. The patented mechanism gently releases the phone.