

4-Port Fiber Optic USB 2.0 Extenders Quick Start Guide


**Break the 16-foot (5-m) USB distance barrier.
This local transmitter/remote receiver pair extends
USB over a duplex fiber link.**

IC404A extends USB over a multimode LC fiber link up to 1600 feet (500 m).

IC406A extends USB over a single-mode LC fiber link up to 6 miles (10 km).

Before you get started, make sure that all the drivers required for your USB device(s) are installed.

1. Place the units where you want them and connect the fiber cabling to the Link ports on the local and remote units.




Trademarks Used in this Manual


Black Box and the Double Diamond logo are registered trademarks of BB Technologies, Inc.

Any other trademarks mentioned in this manual are acknowledged to be the property of the trademark owners

2. Connect the remote unit to the AC adapter.




3. Connect the local unit to the computer.



NOTE: The power adapter is not required at the local unit for normal operation.

4. Attach the USB device(s) to the remote unit.



© Copyright 2010. All rights reserved.

FREE, live, 24/7 Tech Support is just 20 seconds away.
724-746-5500 | blackbox.com